



HOW TO USE:

- 1 - PULL BOTTOM CAP TO REVEAL HIDDEN COMPARTMENT
- 2 - SCREW IN 510 THREAD CARTRIDGE (NOT INCLUDED)
- 3 - SNAP BOTTOM BACK INTO PLACE VIA MAGNETIC LOCK
- 4 - TWIST THE BOTTOM TO ADJUST THE VOLTAGE FROM 2.8V TO 4.0V
- 5 - PUFF 2 TIMES WITHIN 1.5 SECONDS TO PRE-HEAT
- 6 - RAPIDLY PUFF 5 TIMES TO POWER ON/OFF

LED LIGHT INDICATOR:

CONNECTION SUCCESSFUL - WHEN CONNECTING TO THE BASE SUCCESSFULLY, THE BLUE LED WILL LIGHT FOR 1S

LOW VOLTAGE - WHEN THE VOLTAGE IS LOWER THAN 3.2V, THE RED LED WILL FLASH 10 TIMES AND ENTER STANDBY MODE

CHARGING- CONSTANT RED LED

FULLY CHARGED- CONSTANT GREEN LED

VAPING TIMEOUT- RED LED LIGHT FLASHES 4 TIMES WHEN DRAWING FOR OVER 10S

SHORT CIRCUIT PROTECTION/POWER OVERLOAD- RED LED FLASHES 3 TIMES

NO CARTRIDGE DETECTED- WHITE LED FLASHES 3 TIMES

IMPORTANT SAFETY INFORMATION:

- 1 - INTERNAL PARTS OF THE DEVICE REACH HIGH TEMPERATURES.
- 2 - DO NOT DISMANTLE BEYOND CLEANING AND MAINTENANCE, DOING SO WILL VOID THE WARRANTY.
- 3 - DO NOT USE IF DAMAGED.

STORAGE

- 1 - STORE THE DEVICE AT LOW TEMPERATURE (BELOW 68° FAHRENHEIT IS RECOMMENDED) LOW HUMIDITY NO DUST AND NO CORROSIVE GAS ATMOSPHERE.
- 2 - KEEP THE DEVICE AWAY FROM CHILDREN AND PETS TO AVOID ANY ACCIDENTS.

NEU

COVERT SPIN

USER MANUAL & WARRANTY GUIDE



**SCAN TO SEE
THE WARRANTY
POLICY**



**FOLLOW US ON INSTAGRAM
@NEUPIPES**