

COVERT PUFF

USER MANUAL & WARRANTY GUIDE

HOW TO USE:

- 1 - PULL BOTTOM CAP TO REVEAL HIDDEN COMPARTMENT
- 2 - SCREW IN 510 THREAD CARTRIDGE
- 3 - SNAP BACK INTO PLACE VIA MAGNETIC LOCK
- 4 - PUFF 3 TIMES WITHIN 1.5 SECONDS TO CHANGE VOLTAGE (GREEN LIGHT = LOW 3.0 VOLTAGE, RED LIGHT = HIGH 3.8 VOLTAGE)
- 5 - PUFF 2 TIMES WITHIN 1.5 SECONDS TO PRE-HEAT



**SCAN TO SEE
THE WARRANTY
POLICY**

IMPORTANT SAFETY INFORMATION:

- 1 - INTERNAL PARTS OF THE DEVICE REACH HIGH TEMPERATURES.
- 2 - DO NOT DISMANTLE BEYOND CLEANING AND MAINTENANCE, DOING SO WILL VOID THE WARRANTY.
- 3 - DO NOT USE IF DAMAGED.

STORAGE

- 1 - STORE THE DEVICE AT LOW TEMPERATURE (BELOW 68° FAHRENHEIT IS RECOMMENDED), LOW HUMIDITY, NO DUST AND NO CORROSIVE GAS ATMOSPHERE.
- 2 - KEEP THE DEVICE AWAY FROM CHILDREN AND PETS TO AVOID ANY ACCIDENTS.



**FOLLOW US ON INSTAGRAM
@NEUPIPES**